



[www.adaracing.com](http://www.adaracing.com)

## **BladeZ™ Steering Stem Instructions**

- 1) Remove throttle lever, brake lever, and kill switch from stock handlebars.
- 2) Cut the stock handle pole to the desired length. Add 2" for the stem when it's installed. Example: if you want your bars to be 3" lower than stock, cut a total of 5" measuring from the top of the stock bars.
- 3) Mount the handle bars into the steering stem. Slide the stem onto the handle pole. Make sure to align the bars and the front wheel carefully.
- 4) Using a 1/4" drill bit, drill one of the holes in the steering stem through one side of the pole. Now drill from the other side. Now install one of the bolts to hold the stem in place while you drill the holes for the last bolt.
- 5) For final assembly, remove the stem and apply a bead of silicone to the inside of the stem near the top. Now place the stem back onto the pole and secure with the bolts, washers, and nuts. Install and tighten the handlebars. Re-install the brake and throttle lever. Install the new kill switch onto the bars and plug it into the wire where the stock kill switch plugged in.
- 6) Make sure all levers and the kill switch are operating properly. Your done!