



www.adaracing.com

Stalker Air Filter Instructions

Includes:

1 - Billet filter base
1 - Billet filter top
1 - Mesh filter screen
1 - 1/4" fine filter foam
1 - 1/2" pre-filter foam
3 - Internal spacer .9" long
3 - Top mounting bolt 8-32x1-1/4" allen
2 - Carb mounting bolt 5x55mm allen
2 - 5mm lock washer
2 - 5mm flat washer
1 - Stalker to carb gasket

For maximum engine protection it is recommended using a foam filter oil on the 2 foam elements. This helps to block additional smaller particles from passing thru the filter elements.

Use removable Lock-Tite™ on all bolts!

- 1) Remove stock air filter assembly.
- 2) Disassemble Stalker filter, take note of the assembly order of the screen and 2 different filters.
- 3) Mount Stalker base to carb using supplied gasket, 5x55mm bolts, 5mm lock and flat washers. Use removable Lock-Tite™ on these bolts.
- 4) Install the filter screen, the thin foam filter, and then the thicker foam filter. Place the 3 aluminum internal spacers in place.
- 5) Place the top on the filter assembly and tighten using the 8-32 allen bolts, using removable Lock-Tite™.
- 6) Double check the installation and make sure everything was done properly.