



[www.adaracing.com](http://www.adaracing.com)

## **Stalker Exhaust Instructions**

**DO NOT DISASSEMBLE**  
**Canister is packed and sealed**

- 1) Remove plastic engine cover.
- 2) Remove stock exhaust canister and thoroughly clean gasket surface.
- 3) Apply a small amount of thread lock (loc-tite) to mounting bolt threads.
- 4) Mount Stalker to cylinder re-using the stock gasket . If mounting on the G230RC use the additional exhaust spacer and gasket. Mounting holes are slotted for use on different cylinders—center Stalker on exhaust port as close as possible.
- 5) Cut and install plastic engine cover so it does not come in contact with the Stalker exhaust.
- 6) Carburetor tuning may be required for maximum performance.

\*Note: for best noise reduction it is also recommended to use the stock air filter assembly.